



How to install straps



HOW TO REMOVE STRAPS



If possible take a few digital pictures of your chair before the removing process. You will see that will be very helpful when installing the straps. It is a very simple process. Using a pair of scissors or a utility knife cut off all the old straps and remove the fasteners.

HOW TO INSTALL SINGLE WRAP STRAPS

Tools needed for the job:

- Pot of boiling water
- Utility Knife or Scissors
- Gloves
- Towel
- Tong
- Rubber mallet

Step one: Heat the vinyl straps

Heat a pot of water to just under boiling point. Place your straps in the pot and wait about 2 minutes to start installing. The hot water will make it easier to install your straps. We recommend that you wear gloves to protect your hands. When you're ready to start remove one strap using a pair of tongs and dry it with a towel.

Step two: Inserting Rivets

Insert rivets into both ends of the vinyl strap.



How to install straps



Step three: Installing the straps

While the strap is still hot attach the rivet to the hole on one side of the frame (Pic.2)(If necessary use a rubber mallet to tap in the pin) and wrap it around the frame (Pic.3).Using one hand to hold the chair, grab the end of the strap with the other hand (Pic. 4)



and stretch it over the top of the other frame and push the pin into hole (Pic.5), if it is necessary use a rubber mallet or hammer to tap in the rivet (Pic.6).





How to install straps



HOW TO INSTALL DOUBLE WRAP STRAPS

Tools needed for the job:

- Pot of boiling water
- Utility Knife or Scissors
- Gloves
- Towel
- Tong
- Rubber mallet

Step one: Heat the vinyl straps

Heat a pot of water to just under boiling point. Place your straps in the pot and wait about 2 minutes to start installing. The hot water will make it easier to install your straps. We recommend that you wear gloves to protect your hands. When you're ready to start remove one strap using a pair of tongs and dry it with a towel.

Step two: Inserting Rivets

Insert rivets into both ends of the vinyl strap.

Step three: Installing the straps

While the strap is still hot attach the rivet to hole on one side of the frame (Pic.2)(If necessary use a rubber mallet to tap the in the pin) wrap around the frame once so the pin is covered (Pic.3). Using one hand to hold the chair, grab the end of the strap with the other (Pic.4)





How to install straps



and stretch it over the top of the other frame (Pic.5) to the corresponding hole (Pic.6) and wrap it around the bar once (Pic.7 and 8) and push the pin into hole.



If necessary use a rubber mallet to tap in the rivet (Pic.9). Last adjust the strap in place. (Pic.10)



If you have any questions regarding these procedures please [email us](mailto:info@patiochairsupplies.com) at info@patiochairsupplies.com